

MINI HIFI SYSTEM

M 2100



FOR A GOOD REASON

GRUNDIG

CONTENTS

3 SETUP AND SAFETY

4 OVERVIEW

- 4 The hi-fi system controls
- 7 The remote control
- 9 The hi-fi system displays

10 CONNECTION AND PREPARATION

- 10 Connecting the loudspeakers
- 10 Connecting the antenna
- 10 Connecting an MP3 player or a USB memory stick
- 11 Connecting external devices
- 11 Connecting the headphones
- 11 Connecting an external recording device
- 12 Connecting the power cord
- 12 Inserting batteries into the remote control

13 SETTINGS

- 13 Setting the time
- 13 Tuning and storing radio stations

14 GENERAL FUNCTIONS

- 14 Switching on and off
- 14 ECO mode
- 14 Automatic switch-off
- 14 Adjusting the volume
- 14 Selecting sound settings
- 14 Changing the bass or treble
- 14 Loudness
- 14 Muting
- 14 Displaying the time
- 14 Setting the brightness of the display

15 TUNER MODE

- 15 Selecting the tuner input source
- 15 Selecting presets
- 15 Stereo/mono reception
- 15 Displaying RDS station information

16 EXTERNAL DATA MEDIA MODE

- 16 Using CDs
- 16 Operation with an MP3 player or USB memory stick
- 16 Inserting/connecting music data media
- 17 Playback
- 17 Displaying track information (for MP3/WMA)
- 18 Repeat functions
- 18 Playing back tracks in random order (Random)
- 18 Playing the start of each track (intro)
- 19 Creating a playlist

20 BLUETOOTH MODE

- 20 Compatible with the following devices
- 20 Selecting the Bluetooth input source
- 20 Finding and connecting a Bluetooth auxiliary device
- 20 Activating a Bluetooth auxiliary device that is logged on
- 20 Playback from the Bluetooth auxiliary device
- 20 Logging out the Bluetooth auxiliary device

21 USING EXTERNAL DEVICES

- 21 Listening to the audio signal from an external device
- 21 Recording on an external recording device

22 TIMER MODE

- 22 Timer
- 22 Sleep timer

23 INFORMATION

- 23 Cleaning the hi-fi system
- 23 Cleaning the CD unit
- 23 Technical data
- 24 Environmental note
- 24 General information on laser devices
- 25 Troubleshooting

SETUP AND SAFETY

Please note the following instructions:

- The hi-fi system is designed for the playback of audio signals. All other uses are expressly prohibited.
- If you want to set up the hi-fi system on wall shelves or in cupboards, please ensure that it is adequately ventilated. There must be at least 10 cm of space at the side, above and behind the hi-fi system.
- Do not cover the hi-fi system with newspapers, table cloths, curtains, etc.
- When setting up the hi-fi system, remember that furniture is often coated with various types of varnish and plastic, which often contain chemical additives. These additives may cause corrosion to the feet of the unit. This may leave stains on the surface of the furniture which can be difficult or impossible to remove.
- If the hi-fi system is exposed to sudden changes in temperature, for example when taken from the cold into a warm room, wait at least two hours before using it.
- The hi-fi system is designed for use in dry rooms. If you do use it outdoors, make sure it is protected from moisture such as dripping or splashing water.
- Only use the hi-fi system in a moderate climate.
- Do not place the hi-fi system close to heating units or in direct sunlight, as this will impair cooling.
- Do not place any vessels containing liquids, such as vases, on the hi-fi system. Do not insert any foreign objects in the CD compartment.
- Do not place any objects such as burning candles on the hi-fi system.
- If malfunctions occur due to brief mains overloads or static electricity charges, reset the device. To do this, pull out the power plug and connect it again after a few seconds.
- Do not open the hi-fi system casing under any circumstances. Warranty claims are excluded for damage resulting from improper handling.

- Thunderstorms are a danger to all electrical devices. Even if the hi-fi is switched off, it can be damaged by a lightning strike to the mains. Always remove the power plug during a thunder storm.



Prolonged listening with the headphones at loud volumes can damage your hearing.

Note:

- Do not connect any other equipment while the device is switched on. Also switch off the other equipment before connecting it.
- Only plug the device into the mains socket after you have connected the external devices. Make sure the mains plug is freely accessible.


Caution: high-frequency radiation

- The device must be registered and operated in accordance with this operating manual.

The device has an integrated antenna; it must be operated with other antennas or transmitters.








OVERVIEW _____

The hi-fi system controls







OVERVIEW

The front of the device


-  Press briefly to switch the device in and out of standby mode. Press and hold down to activate ECO mode.
-  USB port type A for connecting a USB memory stick or an MP3 player.
-  Infrared sensor for remote control signals.
-  A The hi-fi system displays.
-  B CD compartment.
-  Adjusts the audio volume.
- AUDIO IN** Audio signal input (3.5 mm) for connecting an external device.
-  Headphone jack for connecting a stereo headphone set with a jack plug (3.5 mm). This automatically switches off the loudspeakers.

The top of the device

- SOURCE** Switches the device on from standby mode. Selects the input sources Tuner, Bluetooth, Aux, Audio In, Disc and USB.
-  In tuner mode: press and hold down to start the reverse or forwards frequency search; press briefly to change the frequency backwards or forwards in steps.
In external data media mode: forward or reverse track selection; press and hold down to search for a certain passage forwards or backwards.
In standby and timer mode: to set hours/minutes.
-  In external data media mode: starts and pauses playback.
-  In external data media mode: ends playback.
-  Opens and closes the CD compartment.

OVERVIEW

The back of the device



AC ~ Socket for mains cable.

Note:

- The only way to completely disconnect the hi-fi system from the mains supply is to pull out the plug.

SPEAKER OUT + R - + L - Terminals for connecting the loudspeaker cables.
R = right channel, L = left channel.


LINE OUT Audio signal output for connecting an external recording device.










AUX IN Audio signal input (3.5 mm) for connecting an external device, e.g. an MP3 player.

ANTENNA Antenna socket for the roof antenna or the auxiliary antenna supplied.








OVERVIEW

The remote control




-  Switches the hi-fi system to standby mode and from standby mode to the last input source selected.
-  Opens and closes the CD compartment.
- FM** Selects the tuner input source.
-  Selects the Bluetooth input source.
- CD** Selects the CD input source.
- USB** Selects the USB input source.
- AUDIO IN** Selects the Audio In and Aux input sources for use with an external data medium.
- AUX**
-  In tuner mode: switches between FM stereo and mono reception.
-  Changes the brightness of the display.
- RDS** Opens RDS information.
- INTRO** In external data media mode: for playing brief introductions to tracks.
-  In external data media mode: plays back tracks in random order.
-  In external data media mode: to repeat a track, the CD, the album or the playlist.
- INFO** In external data media mode: switches the display between the current track number and the elapsed playing time and displays the ID3 tag information, if available.
-  In standby: activates the settings for the time.
-  Activates the settings for timer mode.

OVERVIEW

-  In external data media mode: select tracks forwards or backwards.
In standby and timer mode: for setting the hours/minutes.
-  In tuner mode: press and hold down to start the reverse or forwards frequency search;
press briefly to change the frequency backwards or forwards in steps.
In external data media mode: search for a certain passage forwards or backwards.
-  In tuner mode: press and hold down to adopt the RDS time.
In external data media mode: starts playback;
pauses playback.
- SLEEP** Activates sleep timer mode, sets the time for the sleep timer.
- PAIRING**  In external data media mode: ends playback.
In Bluetooth mode: disconnect the connection to the Bluetooth auxiliary device.
-  In external data media mode: select albums.
-  Switches the hi-fi system speakers to and from mute mode.
-  Adjust the volume.
- BASS +** For tuning to radio stations.
- DSC** Selects different sounds settings.
- LOUDNESS** The loudness function provides better sound at lower audio volumes.
- TREBLE +** For tuning to radio stations.
- 1 ... 0** In tuner mode: select preset channels.
- 10 +** In tuner mode: selects the tens for presets.
- PROG** In tuner mode: activates the memory function;
saves radio stations to presets.
In external data media mode: activates the Create playlist function;
stores the track when creating a playlist.

OVERVIEW

The hi-fi system displays



The loudness function is activated.



Data medium mode (disc) selected.



AUX mode selected.



Data media mode (USB) selected.



TUNER mode selected.



The sleep timer is activated.



The timer is activated.



In tuner mode: a stereo FM station is being received.



In standby mode: displays the time.

In any mode: briefly displays the input source; briefly displays the volume and the sound settings.

In tuner mode: displays the station name and RDS information or the waveband and frequency.

In external data media mode: displays the total number of albums and tracks and the elapsed playing time and, if available, the ID3 tag information (ticker text).

ALB

In external data media mode: displays albums.

TRK

In external data media mode: displays tracks.

PRG

In tuner mode: a station is being stored.

In external data media mode: a playlist is being created

SHUF

In external data media mode: random function activated.

REP

In external data media mode: a track is repeated.

ALB REP

In external data media mode: an album is repeated.

REP ALL


In external data media mode: all tracks on the data medium are repeated.

RDS

An RDS station is being received.

CONNECTION AND PREPARATION

Connecting the loudspeakers




- 1 Insert the wires of the loudspeaker cable into the side of the threaded fasteners on the loudspeakers and tighten the threaded fasteners.
- 2 Insert the wires of the loudspeaker cable into the »**SPEAKER OUT R L**« threaded fasteners on the hi-fi system and tighten the threaded fasteners.

Notes:

- Observe the left and right channels (L = left channel, R = right channel).
- Connect each of the red sockets (+) on the hi-fi to the red sockets (+) on the loudspeaker wires.

Connecting the antenna



- 1 Plug the roof antenna cable into the antenna socket »**ANTENNA**« on the hi-fi system.


Note:


- If no roof antenna is available, use the auxiliary antenna supplied. When suitably positioned and with adequate signal, this antenna provides adequate reception of FM channels. Do not shorten the auxiliary antenna.

Connecting an MP3 player or a USB memory stick


Caution:

- The hi-fi system must be switched off while the USB connection is being made. If it is not switched off, data can be lost.



- 1 Connect the USB interface of the MP3 player to the »« socket of the hi-fi system with a standard USB cable;

or


insert the USB plug of the USB memory stick into the USB interface »« of the hi-fi system.

CONNECTION AND PREPARATION

Connecting external devices

Note:

- Switch the hi-fi system off before you connect external devices.





- 1 Use standard audio cables to connect the audio outputs of the external device to the »AUX IN« sockets on the hi-fi system.

Note:

- If possible, connect MP3 players to the »AUDIO IN« socket.

Connecting the headphones



- 1 Insert the headphone plug (3.5 mm) into the »« socket on the hi-fi system.


Note:

- The loudspeakers of the hi-fi system are switched off.

Caution:

- Excessive volume levels when using headphones or earphones can damage your hearing.

Connecting an external recording device




- 1 Use standard audio cables to connect the sound inputs of the external recording device to the »LINE OUT« sockets on the hi-fi system.

CONNECTION AND PREPARATION

Connecting the power cord

Notes:

- Check that the mains voltage on the type plate (on the back of the hi-fi system) corresponds to your local mains supply. If this is not the case, contact your specialist dealer.
- All the other devices/loudspeakers must be connected before you connect the power cord.




- 1 Insert the power cord into the »AC ~« socket on the hi-fi system.
- 2 Plug the power cord into the wall socket.

Caution:

- The hi-fi system is connected to the mains with the power cord. Pull out the power plug if you want to completely disconnect the hi-fi system from the mains.
- Make sure the power plug is easily accessible during operation and not hindered by other objects.

Inserting batteries into the remote control



- 1 Open the battery compartment by pressing down on the catch and then remove the lid.
- 2 Observe the polarity marked on the base of the battery compartment when inserting the batteries (micro batteries, 2 x 1.5 V, R 03/UM 4/AAA).
- 3 Close the battery compartment.

Notes:

- Do not expose the batteries to extreme heat, caused for example by direct sunlight, heaters or fire.
- Remove the batteries when they are flat or when you know that the hi-fi system will not be used for a long period of time. The manufacturer accepts no liability for damage caused by leaking batteries.

Environmental note:

- Batteries, including those which do not contain heavy metal, should not be disposed of with household waste. Always dispose of used batteries in accordance with local environmental regulations.

Setting the time

The first time you connect the hi-fi system to the mains, it switches to standby.

The time can only be changed in standby mode.

1 To set the time in standby mode, press and hold »⏸« for about 2 seconds.

- Display: »CLOCK SET« and then »CLOCK 24 HR«.

2 Select the hour format (12 or 24 hours) by pressing »VOLUME« on the device or by pressing »|◀« or »▶|« on the remote and confirm with »⏸«.

- The hours flash.

3 Set the hours by pressing »VOLUME« on the device or by pressing »|◀« or »▶|« on the remote control and confirm with »⏸«.

- The minutes flash.

4 Set the minutes by pressing »VOLUME« on the device or by pressing »|◀« or »▶|« on the remote control and confirm with »⏸«.

- Display: the current time.

Notes:

- Some RDS stations transmit an RDS time signal. If the selected RDS station transmits time information, the time can be updated automatically.

Press »RDS« repeatedly until the time is displayed. If »RDS CLK« displayed, the time signal has not yet been received. Please wait until the time is displayed.

If the correct time is displayed, press and hold »▶|« to confirm it.

- The time must be reset after a power failure or after disconnecting from the mains.

Tuning and storing radio stations

You can store up to 40 FM radio stations on preset channels.

1 Switch on the hi-fi system by pressing »⏸«, »SOURCE« on the device or »FM« on the remote control.

2 Select the TUNER input source by pressing »SOURCE« on the device or »FM« on the remote control.

Setting and storing radio stations automatically

The device searches for up to 40 stations with strong reception and stores them automatically. After the search has finished, you will hear the station stored at preset 01.

1 Activate the station search by pressing »PROG« until the frequency display changes to rapid run-through.

- Display: »AUTO«.

Setting and storing radio stations manually

1 Set the radio station by briefly pressing »◀◀« or »▶▶« repeatedly on the remote control.

- Display: the frequency changes in steps of 50 kHz;

or

press and hold down »◀◀« or »▶▶« on the remote control until the frequency changes to rapid run-through.


2 Save a radio station as a preset by pressing »PROG«, selecting the preset with »|◀« or »▶|« on the remote control and then press »PROG« to save.

3 To search and save more radio stations, repeat steps 1 to 2.

GENERAL FUNCTIONS


Switching on and off


The only way to disconnect the hi-fi system from the mains supply is to pull out the plug.

1 Switch on the hi-fi by pressing »« or »**SOURCE**« on the device.

- The last input source used is automatically selected.



Note:


- The hi-fi system can also be switched on by pressing »**FM**«, »«, »**CD**«, »**USB**« or »**AUX**« on the remote control.

2 Switch the hi-fi system to standby mode by pressing »«.

ECO mode

You can switch the hi-fi to ECO mode to reduce the power consumption to less than 0.5 W.

1 Press and hold down »« for three seconds.
- In ECO mode, the time display disappears; you can display it briefly by pressing »«.

2 To deactivate ECO mode, press and hold down »« for three seconds.

Automatic switch-off

The device switches off automatically after 15 minutes in standby mode if:

- the device is in the stop position;
- there is no audio signal at the »**AUDIO IN**« or »**AUX IN**« sockets
- the Bluetooth auxiliary devices is not sending an audio signal.

To use the device, switch it back on.

Adjusting the volume

1 Press »**VOLUME**« on the hi-fi or »- **VOL** +« on the remote control to change the volume.

Selecting sound settings

You can choose between preset sound settings.

1 Select the sound setting using »**DSC**« on the remote control.

Changing the bass or treble

1 Change the bass using »- **BASS** +« on the remote control.

2 Change the treble using »- **TREBLE** +« on the remote control.

Loudness

The loudness function provides better sound at lower audio volumes.

1 Switch loudness on and off using »**LOUDNESS**« on the remote control.

Note:

- If you select a sound setting, this cancels your adjustment of the bass, treble or loudness.


Muting


You can switch the hi-fi speakers to and from mute mode with this function.

1 Activate mute with »« on the remote control.


2 Deactivate mute with »« on the remote control.

Displaying the time

1 Display the time with »« on the remote control.

2 Switch off the time with »« on the remote control.

Setting the brightness of the display

1 Adjust the brightness of the display (3 stages) with »« on the remote control.

TUNER MODE

Selecting the tuner input source

- 1 Select the TUNER input source by pressing »**SOURCE**« on the device or »**FM**« on the remote control.
 - The most recently selected station is played (Last Station Memory).

Selecting presets

- 1 Select a preset by pressing »|◀« or »▶|« on the remote control.

Note:

- You can also select the preset with the number buttons »1 ... 0«.
For two-digit preset numbers, first press »10+«. The "10s place" then stays selected.

Stereo/mono reception

When the hi-fi system receives stereo channels, »**Ⓞ**« appears in the display. If the signal from the stereo channel is weak, you can improve the sound quality by switching to mono reception.

- 1 Press »**Ⓞ**« on the remote control to switch to mono reception.
- 2 To switch back to FM stereo, press »**Ⓞ**« on the remote control.

Displaying RDS station information

If the device receives an RDS station, the station name appears in the display together with »**RDS**«. If no information is available, the reception frequency appears in the display.

Additional information can be displayed.

- 1 To display information on the current RDS station, press »**RDS**« repeatedly.
 - The following displays appear in sequence:
 - The name of the radio station.
 - The current programme type (PTY), e.g. »Pop music«. »[No PTY]« appears if information is not available.
 - The time.
 - The radio text.
 - The frequency.

EXTERNAL DATA MEDIA MODE

Using CDs



The device is suitable for music CDs displaying the logo shown here (CD-DA) and for CD-Rs and CD-RWs with audio data.



- The device cannot play CD-ROM, CD-I, CDV, VCD, DVD or computer CDs.
- In MP3/WMA mode, the terms "album" and "file" are very important. "Album" corresponds to a folder on a PC, "file" to a file on a PC or a CD-DA track. An MP3/WMA CD may not contain more than 999 tracks/folders in total.
- When burning CD-R and CD-RWs with audio files, various problems may arise which could lead to problems with playback. This can be caused by faulty software or hardware settings or by the CD being used. Should such problems arise, contact the customer services of your CD burner or software manufacturer or look for relevant information, for example on the Internet.
- When you are making audio CDs, observe all legal guidelines and ensure that the copyright of third parties is not infringed.
- Always keep the CD compartment closed to prevent dust from collecting on the laser optics. The CD compartment closes automatically after a short time.
- Do not attach adhesive labels to CDs. Keep the surfaces of CDs clean.
- You can play standard 12 cm CDs as well as 8 cm CDs on your device. An adapter is not necessary.

Operation with an MP3 player or USB memory stick

- The »↔« socket is not compatible with USB hubs and cannot be connected directly to a PC.
- The USB interface of this device is a standard interface. All currently-known MP3 chip concepts were taken into account when it was developed. Due to rapid progress in MP3 technology and new manufacturers appearing every day, the compatibility of MP3 players/USB memory sticks can only be partially guaranteed.
If USB operation is impaired or is not possible, this does not indicate a malfunction of the device.
- Bi-directional data transfer as defined for ITE devices in EN 55022/EN 555024 is not possible.
- USB transfer is not in itself an operating mode. It is only an additional function.
- Never remove a MP3 player/USB memory stick during playback. This can result in damage to the data and the devices.
No warranty claims are accepted for damage incurred as a result of this.



Inserting/connecting music data media

Inserting the disc


- 1 Press »▲« to open the CD compartment.
 - The CD compartment opens.
- 2 Put in the disc with its label facing upwards.
- 3 Press »▲« to close the CD compartment.
 - The disc is read.
 - Display in MP3/WMA mode: the total number of albums and tracks.
 - Display in CD-DA mode: the total number of tracks and the total playing time.


EXTERNAL DATA MEDIA MODE

Connecting an MP3 player or a USB memory stick

- 1 Switch the device to standby mode by pressing .
- 2 Connect the USB interface of the MP3 player to the  socket of the hi-fi system with a standard USB cable;

or

insert the USB plug of the USB memory stick into the USB interface  of the hi-fi system.

- 3 Switch on the device from standby by pressing .
 - Display: the total number of albums and tracks.


Selecting the input source

- 1 Select the input source (»CD« or »USB«) by pressing »CD« or »USB«.

Playback

Starting playback

When you play music CDs, you can select the track; when you play MP3/WMA files, you can also select folders.

- 1 Playback starts automatically, if necessary press  to start playback;

or



select the folder by pressing   , then select the track with  or .

- Playback starts automatically.
- Display: number of folders and tracks, the name of the track and the elapsed playing time.


Note:

- If no data medium is inserted/connected, the message »NO DISC« or »NO USB« appears.


Pausing and resuming playback

- 1 Press  to pause playback.
 - Display: the playing time flashes.
- 2 Press  to resume playback.

Pausing and resuming playback

- 1 To pause playback, press /PAIRING« once.
 - If you select the data medium again, playback continues from the point at which it stopped.



Stopping playback

- 1 To stop playback, press /PAIRING« twice.
 - When playback starts again, it begins from the first track.





Repeating the current track

- 1 Press  briefly during playback.

Selecting another track


- 1 Press  or  repeatedly during playback until the number of the track you want appears in the display.
 - Playback of the selected track starts automatically.

Searching for a passage within a track

- 1 During playback, press  or  and hold down until the passage has been found.
- 2 Playback begins if you release  or .

Displaying track information (for MP3/WMA)



If information about the artist, album and track are available on the data medium, this is displayed (ID3 tag).

- 1 Press  repeatedly to display information.



EXTERNAL DATA MEDIA MODE

Repeat functions



Repeating a track (Repeat One)

- 1 Press »« once during playback.
 - Display: »**REP**«, the current track is repeated.
- 2 To stop the function, press »« so repeatedly until the display »**REP**« disappears.



Repeating all the tracks of a folder (Repeat Folder) (MP3/WMA only)

- 1 Press »« twice during playback.
 - Display: »**REP**« and »**ALB**« flashes.
 - All the tracks in the current folder are played back repeatedly.
- 2 To stop the function, press »« repeatedly until the display »**REP**« disappears.

Repeating all tracks on the data medium (Repeat All)

- 1 Press »« three times during playback.
 - Display: »**REP ALL**«.
 - All the tracks in the current folder are played back repeatedly.
- 2 To stop the function, press »« repeatedly until the display »**REP ALL**« disappears.

Playing back tracks in random order (Random)

- 1 Press »« during playback.
 - Display: »**SHUF**«.
 - All tracks on the data medium are played back once in random order.
- 2 Press »« to switch off the random function.
 - The display »**SHUF**« disappears.

Playing the start of each track (intro)

- 1 Press »**INTRO**« during playback.
 - Intro playback starts automatically.
 - The first ten seconds of all the tracks or all the remaining tracks on the data medium are played.
- 2 To quit this function, press »**INTRO**« again.

EXTERNAL DATA MEDIA MODE

Creating a playlist

You can create a track memory of up to 32 tracks for the current data medium in any order you choose and then play them back in that sequence. A track may be saved more than once.

The entries can only be made in stop mode.

Selecting and storing tracks

- 1 Press **■/PAIRING** to end playback.
- 2 Press **»PROG«** to open the function.
 - Display: **» I I P - - 0 I«, »PRG«** lights up.
- 3 Select the folder by pressing **»+ [] -«**, then select the track with **»|«** or **»|«** and save it with **»PROG«**.
 - Display: **» I 2 P - - 0 2«, »PRG«** lights up.
- 4 To store more tracks, repeat step 3.

Playing back a playlist

- 1 Start playlist playback with **»▶||«**.
 - Playback begins with the first programmed track.
- 2 Press **■/PAIRING** once to stop playback.
- 3 To play the playlist again, press **»PROG«** in the stop position, followed by **»▶||«**.

Deleting the playlist

- 1 To delete the playlist, press **■/PAIRING** twice in the stop position;
 - or
 - open the CD compartment;
 - or
 - select a different input source.


BLUETOOTH MODE



Compatible with the following devices

Your M 2100 can be connected to any commercially available Bluetooth-compatible devices that comply with the A2DP standard. This includes smartphones, laptops and tablet PCs, for example.

Selecting the Bluetooth input source

- 1 Select the Bluetooth input source by pressing »SOURCE« on the device or »« on the remote control.
 - Display: »BT DISCONNECT«.

Finding and connecting a Bluetooth auxiliary device

- 1 Activate the Bluetooth function on the Bluetooth auxiliary device.
- 2 Start the search function on the Bluetooth auxiliary device.
 - After a short time, your M 2100 will be displayed on the Bluetooth auxiliary device.
- 3 Select the M 2100 on the Bluetooth auxiliary device and connect to it.
- 4 When the Bluetooth auxiliary device is connected to your device, »BT« is displayed on the M 2100.

Note:

- Your M 2100 can only receive and play the audio signal from one Bluetooth device; however, up to 8 Bluetooth auxiliary devices can be logged on.

Activating a Bluetooth auxiliary device that is logged on

Notes:

- You only have to log Bluetooth auxiliary devices on once.
- When the Bluetooth auxiliary device leaves and then moves back into signal range of the M 2100, the auxiliary device logs on automatically.

- The M 2100 automatically connects to the last Bluetooth auxiliary device that was logged on.
- If the Bluetooth auxiliary device is not recognised, it has to be activated again via its own menu.

Playback from the Bluetooth auxiliary device

- 1 Start playback on the Bluetooth auxiliary device.
- 2 Set the preferred volume with »VOLUME« on the hi-fi or »- VOL +« on the remote control.
- 3 End playback on the Bluetooth auxiliary device.

Notes:

- Various functions can also be controlled on the M 2100.
 - Press »▶II« to pause playback, press »▶II« again to resume playback; press »|◀« to select the previous track and »▶|« for the next track.
- Note that the data transmission range can be as much as 9 m, depending on the Bluetooth device that is used and the structure of the building.

Logging out the Bluetooth auxiliary device

- 1 Log out the Bluetooth device or press and hold down »■/PAIRING« on the M 2100.
 - The display changes to »SEARCHING«.

Logging the Bluetooth device back on

- 1 If you move out of data transmission range or switch off Bluetooth mode, the Bluetooth auxiliary device is logged out.
- 2 To log back on, select your M 2100 again on the Bluetooth auxiliary device.

Note:

- If it is not possible to connect to a Bluetooth auxiliary device that was registered previously, remove your M 2100 from the Bluetooth auxiliary device's device list and repeat the search and connection procedure.

USING EXTERNAL DEVICES

Listening to the audio signal from an external device

You can play the audio signal from an external device (e.g. an MP3 player) on the hi-fi system.

Notes:

- The external devices must be connected to the »**AUX IN**« socket or the »**AUDIO IN**« socket.
 - If possible, connect MP3 players to the »**AUDIO IN**« socket.
- 1 Switch on the device from standby by pressing »**⏻**«.
 - 2 Select the AUDIO IN or AUX input source by pressing »**SOURCE**« on the device or »**AUDIO IN AUX**« on the remote control.
 - Display: »**AUDIO IN**« or »**AUX**«.
 - 3 Start playback on the external device.

Recording on an external recording device

Note:

- The external recording device must be connected to the »**LINE OUT**« socket.

- 1 Select the input source by pressing »**FM**«, »**CD**«, »**USB**«, »**Ⓛ**« or »**AUDIO IN AUX**«.
- 2 Connect/insert data medium and start playback;

or
select radio station.
- 3 Start recording on the external recording device.

TIMER MODE

Your hi-fi system has two timer modes:

- The timer, which switches the hi-fi system on at a preset time and wakes you with the input source you selected.
- The sleep timer, which switches the hi-fi system off at a preset time.

Notes:

- You can only set the timer mode with the buttons on the remote control.
- The time has to be set on the hi-fi system.
- When this setting is being made, if no button is pushed for more than 10 seconds, the hi-fi system will end the process automatically. You then have to start again.

Timer

Setting the timer

- 1 Press »⏰« from the switched off state.
 - Display: »TIMER SET« appears, followed by the last input source selected.
- 2 Select the input source (TUNER, DAB, DISC or USB) by pressing »|« or »|« and confirm with »⏰«.
 - Display: the hours of the switch-off time flash.

Note:

- If you selected the signal source DISC or USB and the file is damaged or there is no CD in the CD compartment, the hi-fi automatically switches to TUNER mode.

- 3 Enter the hours of the switch-on time with »|« or »|« and confirm with »⏰«.
Enter the minutes of the switch-on time with »|« or »|« and confirm with »⏰«.
 - Display: »VOL«.
- 4 Set the volume with »|« or »|« and confirm with »⏰«.
 - Display: the current time and »⏰«.
 - The timer is activated

Activating and deactivating the alarm

- 1 Deactivate the alarm by pressing »⏰« once briefly.
 - Display: »⏰« disappears when the timer is deactivated.

Sleep timer

Setting the sleep timer

- 1 Switch on the hi-fi system from standby by pressing »⏰«.
- 2 Open the function with »SLEEP« on the remote control.
 - Display: »SLEEP - -OFF«.
- 3 Select the switch-off time (» 10«, »20« to »30«, »OFF«) with »SLEEP«.
 - Display: e.g. »SLEEP - -30«, is displayed briefly, then the selected input source and »z«.
 - The hi-fi system switches off after the selected time has elapsed.

Ending the sleep timer prematurely

- 1 To end the sleep timer prematurely, press »SLEEP« repeatedly until »SLEEP - -OFF« appears in the display and »z« disappears;


or

switch the hi-fi system to standby mode by pressing »⏰«.

Cleaning the hi-fi system

Pull the power cord out of the mains socket. Clean the appliance with a damp cloth and a mild detergent. Do not use any detergents containing alcohol, spirit, ammonia or scouring agent.

Cleaning the CD unit



If the device is unable to scan CDs properly, use a standard, commercially available cleaning CD to clean the laser optics. Other cleaning methods may damage the laser optics.

Use a lint-free cloth for cleaning the CD and always wipe it from the inside out in a straight line. Do not use cleaning agents for conventional vinyl discs, nor any solvents or abrasive cleaners.

Technical data



This device is noise-suppressed according to the applicable EU directives.

This product fulfils the European directives 1999/5/EC, 2009/125/EC and 2011/65/EU.

The type plate is located on the back of the hi-fi system.

System

Power supply

Operating voltage: 220 - 240 V~
Mains frequency: 50/60 Hz
Max. power consumption: 25 W
Power consumption (ECO mode): ≤ 0.5 W

Amplifier unit

output:

Sine wave power: 2 x 25 W
Loudspeaker impedance: 6 Ω
Signal-to-noise ratio: ≥ 80 dBA

Receiver unit

Reception range:

FM: 87.5 ...108.0 MHz

CD unit

Frequency response: 20 Hz ... 20 kHz

Noise voltage ratio: ≥ 96 dBA

MP3/WMA

Folder and track:

Max. 256 folders and 999 tracks per CD

File system/folder management:

ISO 9660 Level 1 compatible

USB

USB 2.0 for FAT 32/16 format

Dimensions and weight

Device dimensions (with threaded fasteners):

W x H x L 260 x 100 x 300 mm

Device weight: 1.9 kg

Loudspeaker dimensions:

W x H x L 155 x 240 x 235 mm

Loudspeaker weight: 2.37 kg

Technical and design modifications are reserved.

Environmental note



This product has been made from high-quality parts and materials which can be re-used and recycled.

Therefore, do not dispose of the product along with normal household waste at the end of its service life. Take it to a collection point for the recycling of electrical and electronic equipment. The symbol on the product, in the operating manual or on the packaging indicates that recycling is possible.

Please find out about collection points operated by your local authority.

Help protect the environment by recycling used products.

General information on laser devices

CLASS 1 M
LASER PRODUCT

This device is a CLASS 1 M LASER PRODUCT.

This means that the laser is designed in such a way as to ensure that the maximum permissible emission value cannot be exceeded under any circumstances.

Caution:

If operating devices or methods other than those specified here are employed, it may lead to dangerous exposure to emissions.

This device emits laser radiation. Because of the danger of eye injuries, the unit may only be opened or serviced by trained personnel.

If settings other than those stated here are used or other procedures are carried out, this may lead to dangerous exposure to radiation.

INFORMATION

Troubleshooting

Not every kind of sound interference is caused by a defect in your hi-fi system. Cables that have accidentally been disconnected, damaged CDs and flat batteries for the remote control will impair functioning. If the following measures do

not resolve the problem satisfactorily, please visit www.grundig.com, product range: hi-fi, micro CD stations or contact your specialist dealer.

Problem	Possible cause/remedy
»NO DISC« is displayed.	Insert a CD.
	Check that the CD was inserted with the label facing upwards.
	Moisture may have collected on the laser lens; wipe it clean.
	Clean the CD (see "INFORMATION") or use a different CD.
Poor radio reception.	The CD-RW/CD-R is not finalised.
	Reception signal too weak; position the wire antenna differently. Move the hi-fi further away from the television.
The hi-fi system does not react when the buttons are pressed.	Disconnect the power cord from the mains plug, reinsert it after a short time and switch the hi-fi back on.
Sound too quiet or poor sound quality.	Turn up the volume.
	Loudspeakers connected properly?
	Pull out the headphones jack. Check the loudspeaker connections.
Stereo sounds wrong.	Loudspeakers connected properly?
The remote control does not work.	First select the input source then use the function buttons.
	Hold the remote control closer to the hi-fi.
	Check the polarity of the batteries.
	Insert new batteries. Point the remote control directly at the receiver on the front of the hi-fi.
The timer function does not work.	Set the time.
	Activate the timer function with »⏸«.
Time and timer setting not displayed.	Power failure or the power plug has been pulled out of the wall socket. Set the time.
CD-Rs or CD-RWs are not played back, or are played back incorrectly.	The CD is faulty or the software or hardware settings were incorrect during burning Check the components of your CD burner/burner software or change the CD you are using
During playback of a track, the device switches to a different folder.	If the current folder contains a faulty track or a track with an invalid name, the device automatically switches to another folder.

Grundig Intermedia GmbH
Beuthener Strasse 41
90471 Nürnberg

www.grundig.com
72011 909 1600 13/34

AUS GUTEM GRUND

GRUNDIG