



- 1** No rinse agent / No salt / Water cut off indicator
- 2** Programme lights
- 3** Half Load indicators
- 4** Express Indicators

- 5** Delayed Start indicator
- 6** Programme follow-up indicators
- 7** Start/Pause/Cancel button
- 8** Delayed Start button

- 9** Express Function button
- 10** Half Load button
- 11** Programme Selection button
- 12** On/Off button

Function keys

On/Off button

To turn the machine on, press and hold down the On/Off button for 1 second. Indicator lights on the panel will illuminate. To turn the machine off, press and hold down the On/Off button for 1 second. In Off position, indicator lights will turn off.

Programme Selection button

Refer to "Table of Programme Data and Average Consumption Values" to select a programme suitable for your dishes. Press the Programme Selection key repeatedly until the light of the programme you want to select is illuminated.

Start/Pause/Cancel button

It is used to start, pause or cancel a selected programme or function. When you press the Start / Pause / Cancel key, the washing programme you have selected will start. When your machine is in "Pause" mode, one of the programme follow up buttons will flash.

⚠ **To press the Start / Pause / Cancel key, wait for two seconds after you turn on your machine by pressing the On / Off key.**

Canceling a programme

Press Start / Pause / Cancel key for 3 seconds to cancel the programme. Stop pressing when Washing and Drying lights flash at the same time. Water in the machine will be discharged in 45 seconds. When the End light comes on, the programme will have been cancelled. Then, you can select and operate a new programme.

⚠ **There might be residues of detergent or rinse aid left in the machine and / or on the pieces washed depending on the step the programme you have cancelled was in.**

Water Cut Off Indicator

If the machine cannot take in water, then the Water Cut Off Indicator will light on the screen. Once the water flows in, the warning indicator will automatically switch off.

⚠ **When the Water Cut Off indicator lights, make sure that the water is not cut-off and that the tap is off. Call Authorised Service Agent if water is not cut-off and the tap is open.**

Half Load button

If you want to run your machine without loading it completely, place your dishes into the machine as you desire. First press the On/Off button. After you have chosen the programme of your choice, press the Half Load button and see that the Half Load light on the panel is on. Start the programme by pressing the Start/Pause/Cancel button and you can save water and power. You can use every part of the upper and lower baskets by choosing Half Load.

Express Function

It shortens the time of the washing cycle selected and decreases water consumption by enabling washing under higher pressure.

Delayed Start

You can delay the startup of the programme up to 9 hours with Delayed Start button. Press Start/Pause/Cancel key after setting the Delayed Start. Once the delay time is over, the selected programme will start automatically.

Every time you press the delayed start button, the 3-6-9 hour lights will start flashing respectively. If you press on the Start/Delay/Cancel button while the selected delayed start button is flashing, the delayed start light will stay on and the countdown will start. When the delay period is completed, the delayed start light will go off and the selected washing programme will begin.

⚠ While the 9 hour delayed start lamp is flashing, if you press the Delayed Start button, the delayed start lights will go off. If you press the Start/Delay/Cancel button while the Delayed Start Lights are off, the programme you have selected will start without any delay period.

⚠ You can follow the amount of delay time left from the delayed start lights. For Example: Once you have chosen the 9-hour delay period, when 6 hours is left for the washing programme to start, the 6-hour light will come on and when there is 3 hours left, the 3-hour light will come on.

Changing the Delayed Start Time

Press the Start/Pause/Cancel button. The delay time light will start flashing. You can select the new delay period by pressing the Delayed Start button again. Save this by pressing Start/Pause/Cancel key again.

To cancel the Delayed Start;

Press and hold Start / Pause / Cancel key for 3 seconds. The selected delay time will have been cancelled. Once the cancellation has started, the water left in the machine will be discharged in 30 seconds.

Starting your machine

1. Open the tap.
 2. Plug in to the socket.
 3. Open the door of the dishwasher.
 4. Place the dishes in accordance with the instructions in the user manual.
 5. Make sure that the upper and lower impellers rotate freely.
 6. Put sufficient amount of detergent in the detergent dispenser and close its lid.
 7. Make sure that the lights on programme display are illuminated by pressing On / Off key.
 8. Check if the Salt and Rinse Aid indicators light and add salt and / or rinse aid if needed.
- △ **Since different salt brands in the market have different particle sizes and the water hardness may vary, dissolution of the salt in water may take a couple of hours. Therefore, the No Salt warning light will remain on for a while after adding salt into the machine.**
9. Select the most suitable programme by using the "Table of Programme Data and Consumption Values".
 10. Select the desired programme you want to run with the Programme Selection button.
 11. Press Start / Pause / Cancel key to start the programme.

- △ **Pay attention not to open the door of the machine while it is running. If you need to open the door, safety system will stop your machine. There may be a rush of vapour when you open the door of your machine; be careful. The programme will resume running when you close the door.**
- △ **If the Drying lamp is on, the machine will be drying silently for 35-45 minutes. After a while, the Drying lamp will switch off and the End lamp will come on.**
- △ **Make sure you wait for the drying to finish before switching off your machine. After the End light has come on, switch the machine off by pressing the On/Off button.**
12. Press the On/Off key to switch off the machine.
 13. Close the tap.
 14. Unplug the machine from the socket.
 15. Leave your dishes in the machine for about 15 minutes after they are washed in order to have them cooled down. Your dishes will dry in a shorter time if you leave the door of your machine ajar during this period. This will increase the drying effectiveness of your machine.

Programme Table

Programme number	1	2	3	4	5	6
Programme name	Eco (Eko *)	Auto (Otomatik)	Intensive (Yoğun)	Express (Hızlı 58')	Mini (Mini 30')	Prewash (Ön Yıkama)
Cleaning temperature	50 °C	40-65 °C	70 °C	60 °C	35 °C	-
Degree of Soiling	Most economical washing programme for the medium soiled daily dishes that are kept waiting.	Determines the soiling degree of the dishes and sets the temperature and amount of the washing water as well as the washing time automatically. Suitable for all types of dishes.	Suitable for heavily soiled dishes, pots and pans.	Daily washing programme for normally soiled dishes in the fastest way.	Suitable for lightly soiled daily dishes that are scraped or pre-cleaned.	Suitable for removing the remnants on the soiled dishes that will be kept waiting in the machine for a few days, and thus, for preventing the bad odour buildup.
	Medium	Medium to high	High	Medium	Low	-
Detergents A=25 cm ³ /15 cm ³ B=5 cm ³	A+B	A	A+B	A+B	A	-
Prewash	+	+	+	-	-	+
Wash	+	+	+	+	+	-
Dry	+	+	+	+	-	-
Duration (min)	225	92-176	140	58	30	15
Water (l)	11	12,6-17,0	17,6	11,8	11,8	4,2
Energy (kWh)	1,03	1,02-1,68	1,55	1,20	0,74	-

The consumption values shown in the table were determined under standard conditions. Differences may therefore occur under practical conditions. * Reference programme for testing institutes. The tests in accordance with EN 50242 must be carried out with a full water softener salt dispenser and a full rinse aid reservoir, and using the test programme.