




# *Dryer*

## *User manual*

*3890 KT*



# Please read this user manual first!

Dear Customer,

Thank you for preferring a Arçelik product. We hope that your product which has been manufactured with high quality and technology will give you the best results. We advise you to read through this manual and the other accompanying documentation carefully before using your product and keep it for future reference. If you transfer the product to someone else, give its manual as well. Pay attention to all details and warnings specified in the user manual and follow the instructions given therein.

Use this user manual for the model indicated on the cover page.

## Explanation of symbols

Throughout this user manual the following symbols are used:

	Important information or useful hints about usage.
	Warning for hazardous situations with regard to life and property.
	Warning against electric shock.
	Warning against hot surfaces.
	Warning against fire hazard.
	Packaging materials of the product are manufactured from recyclable materials in accordance with our National Environment Regulations.

Do not dispose of the packaging wastes with the domestic waste or other wastes, discard them to the dedicated collection points designated by the local authorities.



This product was manufactured using the latest technology in environmentally friendly conditions.



WEEE It complies with the WEEE Directive

# 1 Important instructions for safety and environment

This section contains safety instructions that will help protect from risk of personal injury or property damage. Failure to follow these instructions shall void any warranty.

## 1.1 General safety

- The dryer can be used by children at and above 8 years old and by persons whose physical, sensory or mental capabilities were not fully developed or who lack experience and knowledge provided that they are supervised or trained on the safe usage of the product and the risks it brings out. Children should not play with the product. Cleaning and maintenance works should not be performed by children unless they are supervised by someone.
- Children of less than 3 years should be kept away unless continuously supervised.
- Adjustable feet should not be removed. The gap between the dryer and the floor should not be reduced with materials such as carpet, wood and tape. This will cause problems with the dryer.
- Always have the installation and repairing procedures carried out by the **Authorized Service**. Manufacturer shall not be held liable for damages that may arise from procedures carried out by unauthorized persons.
- Never wash the dryer by spraying or pouring water onto it! There is the risk of electric shock!

# Important instructions for safety and environment

## 1.1.1 Electrical safety



Electrical safety instructions should be followed while electrical connection is made during the installation.

- Connect the dryer to a grounded outlet protected by a fuse at the value specified on the type label. Have the grounding installation performed by a qualified electrician. Our company shall not be liable for any damages that will arise when the dryer is used without grounding in accordance with the local regulations.
- The voltage and allowed fuse protection is stated on the type label plate.
- The voltage specified on the type label must be equal to your mains voltage.
- Unplug the dryer when it is not in use.
- Unplug the dryer from the mains during installation, maintenance, cleaning and repair works.
- Do not touch the plug with wet hands! Never unplug by pulling on the cable, always pull out by grabbing the plug.
- Do not use extension cords, multi-plugs or adaptors to connect the dryer to power supply in order to decrease the risk of fire and electric shock.
- Power cable plug must be easily accessible after installation.



Damaged mains cable should be changed notifying the Authorized Service.



If the dryer is faulty, it must not be operated unless it is repaired by an authorized service agent! There is the risk of electric shock!

# Important instructions for safety and environment

## 1.1.2 Product safety



### **Points to be taken into consideration for fire hazard:**

Below specified laundry or items must not be dried in the dryer considering fire hazard.

- Unwashed laundry items
- Items soiled with oil, acetone, alcohol, fuel oil, kerosene, stain removers, turpentine, paraffin or paraffin removers must be washed in hot water with plenty of detergent before being dried in the dryer.

For this reason especially the items containing the above specified stains must be washed very well, to do this use adequate detergent and choose a high washing temperature.



### **Below specified laundry or items must not be dried in the dryer due to the fire hazard:**

- Garments or pillows bolstered with rubber foam (latex foam), shower bonnets, water resistant textiles, materials with rubber reinforcement and rubber foam pads.
- Clothing cleaned with industrial chemicals.

Items such as lighter, match, coins, metal parts, needle etc. may damage the drum set or may lead to functional problems. Therefore check all the laundry that you will load into your dryer. Never stop your dryer before the programme completes. If you must do this, remove all laundry quickly and lay them out to dissipate the heat.



Clothes that are washed inadequately may ignite on their own and even may ignite after drying ends.

- You must provide enough ventilation in order to prevent gases exiting from devices operating with other types of fuels including the naked flame from accumulating in the room due to the back fire effect.

## Important instructions for safety and environment



Underwear that contains metal reinforcements should not be dried in the dryer. Dryer may be damaged if metal reinforcements come loose and break off during drying.



Use softeners and similar products in accordance with the instructions of their manufacturers.



Always clean the lint filter before or after each loading. Never operate the dryer without the lint filter installed.

- Never attempt to repair the dryer by yourself. Do not perform any repair or replacement procedures on the product even if you know or have the ability to perform the required procedure unless it is clearly suggested in the operating instructions or the published service manual. Otherwise, you will be putting your life and others' lives in danger.
- There must not be a lockable, sliding or hinged door that may block the opening of the loading door in the place where your dryer is to be installed.
- Install your dryer at places suitable for home use. (Bathroom, closed balcony, garage etc.)
- Make sure that pets do not enter the dryer. Check the inside of the dryer before operating it.
- Do not lean on the loading door of your dryer when it is open, otherwise it may fall over.
- The lint must not be allowed to accumulate around the tumble dryer

### 1.2 Mounting over a washing machine

- A fixing device should be used between the two machines when installing the dryer above a washing machine. The fitting device must be installed by the authorized service agent.
- Total weight of the washing machine and the dryer -with full load- when they are placed on top of each other reaches to approx. 180 kilograms. Place the products on a solid floor that has sufficient load carrying capacity!

## Important instructions for safety and environment



Washing machine cannot be placed on the dryer. Pay attention to the above warnings during the installation on your washing machine.

**Installation Table for Washing Machine and Dryer**

Dryer Depth	Washing Machine Depth						
	62 cm	60 cm	54 cm	50 cm	49 cm	45 cm	40 cm
54 cm	Can be installed					Can be installed	Cannot be installed
60 cm	Can be installed					Cannot be installed	

### 1.3 Intended use

- Dryer has been designed for domestic use. It is not suitable for commercial use and it must not be used out of its intended use.
- Use the dryer only for drying laundry that are marked accordingly.
- The manufacturer waives any responsibility arisen from incorrect usage or transportation.
- The service life of the dryer that you purchased is 10 years. During this period, original spare parts will be available to operate the dryer properly.

### 1.4 Child safety

- Packaging materials are dangerous for the children. Keep packaging materials away from children.
- Electrical products are dangerous for the children. Keep children away from the product when it is operating. Do not let them tamper with the dryer. Use the child-proof lock in order to prevent the children to tamper with the dryer.



Child-proof lock is on the control panel. **(See Child lock)**

- Keep loading door closed even when the dryer is not in use.

### 1.5 Compliance with the WEEE regulation and disposing of the waste product

# Important instructions for safety and environment



This product complies with EU WEEE Directive (2012/19/EU). This product bears a classification symbol for waste electrical and electronic equipment (WEEE).

This product has been manufactured with high quality parts and materials which can be reused and are suitable for recycling. Do not dispose of the waste product with normal domestic and other wastes at the end of its service life. Take it to the collection center for the recycling of electrical and electronic equipment. Please consult your local authorities to learn about these collection centers.

## 1.6 Compliance with RoHS Directive:

The product you have purchased complies with EU RoHS Directive (2011/65/EU). It does not contain harmful and prohibited materials specified in the Directive.

## 1.7 Package information

Packaging materials of the product are manufactured from recyclable materials in accordance with our National Environment Regulations. Do not dispose of the packaging materials together with the domestic or other wastes. Take them to the packaging material collection points designated by the local authorities.

## 1.8 Technical Specifications

\* Min. height: Height with adjustable feet are closed.

Max. height: Height with adjustable feet are opened maximum.

EN	
Height (Min. / Max.)	84,6 cm / 86,6 cm*
Width	59,5 cm
Depth	59,8 cm
Capacity (max.)	9 kg**
Net weight (plastic front door usage)	51 kg
Net weight (glass front door usage)	53 kg
Voltage	See type label***
Rated power input	
Model code	

\*\* Dry laundry weight before washing.

\*\*\* Type label is located behind the loading door.



Technical specifications of the dryer are subject to specification without notice to improve the quality of the product.




Figures in this manual are schematic and may not match the product exactly.



Values stated on markers on the dryer or in the other published documentation accompanying with the dryer are obtained in laboratory in accordance with the relevant standards. Depending on operational and environmental conditions of the dryer, these values may vary.


## 2 Your Dryer

### 2.1 Overview



1. Top panel
2. Control panel
3. Loading door
4. Kick plate opening button
5. Ventilation grids
6. Adjustable legs
7. Kick plate
8. Type label
9. Lint filter
10. Water tank drawer
11. Power cord

## 2.2 Package Contents



1. Water drain hose \*
2. Filter drawer spare sponge\*
3. User Manual
4. Drying basket\*
5. Drying basket user manual\*

\*It can be supplied with your machine depending on its model.

## 3 Installation

Before the calling the nearest Authorized Service for the installation of the dryer, ensure that electrical installation and water drain is appropriate referring to the user's manual. **(See 3.3 Connecting to the drain and 3.5 Electrical connection)** If they are not suitable, contact a qualified electrician and technician to make necessary arrangements.



Preparation of the dryer's location as well as the electrical and waste water installations is under customer's responsibility.



Prior to installation, visually check if the dryer has any defects on it. If the drier is damaged, do not have it installed. Damaged products cause risks for your safety.



Let your dryer wait for 12 hours before starting to use it.

### 3.1 Appropriate installation location

- Install the dryer on a stable and level surface.
- Dryer is heavy. Do not move it by yourself.
- Operate your dryer in a well ventilated, dust-free environment.
- The gap between the dryer and the surface should not be reduced by the materials such as carpet, wood and tape.
- Do not cover the ventilation grills of the dryer.
- There must not be a lockable, sliding or hinged door that may block the opening of the loading door in the place where your dryer is to be installed.
- Once the dryer is installed, it should stay at the same place where its connections have been made. When installing the dryer, make sure that its rear wall does not touch anywhere (tap, socket, etc.).
- Place the dryer at least 1 cm away from the edges of other furniture.
- Your dryer can be operated at temperatures between +5°C and +35°C. If the operating conditions fall outside of this range, operation of the dryer will be adversely affected and it can get damaged.
- The rear surface of the tumble dryer shall be placed against a wall.




Do not place the dryer on the power cable.

### 3.2 Removing the transportation safety assembly



Remove the transportation safety assembly before using the dryer for the first time.

- Open the loading door.
- There is a nylon bag inside the drum that contains a piece of styrofoam. Hold it from its section marked with XX XX.
- Pull the nylon towards yourself and remove the transportation safety assembly.



Check that no part of the transportation safety assembly remains inside the drum.

### 3.3 Connecting to the drain

In products equipped with condenser unit, water accumulates in the water tank during the drying cycle. You should drain accumulated water after each drying cycle.


You can directly drain accumulated water through the water drain hose supplied with the product instead of periodically draining the water collected in the water tank.

Please refer to the detailed instructions supplied with the accessories pack.

#### Connecting the water drain hose

- 1-2** Pull hose at the behind of the dryer by hand in order to disconnect it from where it is connected. Do not use any tools to remove the hose.
- 3** Connect one end of the drain hose supplied with the dryer to the connection point from where you removed the hose of the product in previous step.
- 4** Connect the other end of the drain hose directly to the wastewater drain or to the washbasin.

# Installation



Hose connection should be made in a safe manner. Your drain house will be flooded if the hose comes out of its housing during water discharge.




Water drain hose should be attached to a height of maximum 100 cm.



Make sure that the water drain hose is not stepped on and it is not folded between the drain and the machine.

## 3.4 Adjusting the feet

- In order to ensure that the dryer operates more silently and vibration-free, it must stand level and balanced on its feet. Balance the machine by adjusting the feet.
- Turn the feet to left or right until the dryer stands level and firmly.



Never unscrew the adjustable feet from their housings.

## 3.5 Electrical connection

For specific instructions for electrical connection required during installation (see 1.1.1 Electrical Safety)

## 3.6 Transportation of the dryer

- Unplug the dryer before transporting it.
  - Drain all water that has remained in the dryer.
- If direct water drain connection is made, then remove the hose connections.




We recommend carrying the dryer in upright position. If it is not possible to carry the machine in the upright position, we recommend carrying it by tilting towards the right side when looked from the front.


## 3.7 Warnings about sounds



It is normal to hear a metallic noise from the compressor sometimes during operation.



Water collected during operation is pumped to water tank. It is normal to hear pumping noise during this process.



## 3.8 Changing the illumination lamp

In case an illumination lamp is used in your laundry dryer. To change the Bulb/LED used for illumination of your tumble dryer, call your Authorized Service. The lamp(s) used in this appliance is not suitable for household room illumination. The intended purpose of this lamp is to assist the user to place laundry in the tumble dryer in a comfortable way. The lamps used in this appliance have to withstand extreme physical conditions such as vibrations and temperatures above 50 °C.

## 4 Preparation

### 4.1 Laundry suitable for drying in the dryer

- Always obey the instructions given on the garment tags. Dry only the laundry having a label stating that they are suitable for drying in a dryer and make sure that you select the appropriate programme.

LAUNDRY DRYING SYMBOLS											
	Drying Symbols										
	Drying Settings										
	Iron -										
IRON	Dry or Steam	Iron at high temperature	Iron at medium temperature	Iron at low temperature	Do not iron	Do not iron	Do not iron	Do not iron	Do not iron	Do not iron	Do not iron
	Maximum temperature	200 °C	150 °C	110 °C							

### 4.2 Laundry not suitable for drying in the dryer



Delicate embroidered fabrics, woollen, silk garments, delicate and valuable fabrics, airtight items and tulle curtains are not suitable for machine drying.


### 4.3 Preparing laundry for drying

- Laundry may be tangled with each other after washing. Separate the laundry items before placing them into the dryer.
- Dry garments having metal accessories such as zippers, inside out.
- Fasten the zippers, hooks and buckles and button sheets.

### 4.4 Things to be done for energy saving


- Following information will help you use the dryer in an ecological and energy-efficient manner.
- Spin your laundry at the highest speed possible when washing them. Thus, the drying time is shortened and energy consumption is reduced.
- Sort out the laundry depending on their type and thickness. Dry the same type of laundry together. For example thin kitchen towels and table clothes dries earlier than thick bathroom towels.
- Follow the instructions in the user manual for programme selection.
- Do not open the loading door of the machine during drying unless necessary. If you must certainly open the loading door, do not to keep it open for a long time.
- Do not add wet laundry while the dryer is in operation
- Clean the lint filter before or after each drying cycle.  
**(See 6.1 Cleaning Lint Filter / Loading Door Inner Surface)**

## Preparation

- Clean the filter periodically when there is visible air collection on it or when the symbol lights up, if there is a filter drawer cleaning warning symbol «  » available. (See 6. 4 Cleaning the filter drawer)
- Ventilate the room, where the dryer is located, well during drying.

### 4.5 Correct load capacity

Follow the instructions in the "Programme selection and consumption table". Do not load more than the capacity values stated in the table.



It is not recommended to load the dryer with laundry exceeding the level indicated in the figure. Drying performance will degrade when the machine is overloaded. Furthermore, dryer and the laundry can get damaged.


Following weights are given as examples.

Laundry	Approximate weights (g)*
Cotton quit covers (double)	1500
Cotton quit covers (single)	1000
Bed sheets (double)	500
Bed sheets (single)	350
Large tablecloths	700
Small tablecloths	250
Tea napkins	100
Bath towels	700
Hand towels	350
Blouses	150
Cotton shirts	300
Shirts	250
Cotton dresses	500
Dresses	350
Jeans	700
Handkerchiefs (10 pieces)	100
T-Shirts	125

\*Dry laundry weight before washing.


## 5 Program selection and operating your machine

### 5.1 Control Panel



1. On/Off/Cancel button
2. Program number indicator
3. Display
4. Start/standby button Sound warning level button/child lock
5. Time delay selection button
6. Sound warning level button/child lock
7. Timing / Steam program selection button
8. Program selection button

### 5.2 Screen Symbols



- Remaining time indicator\*
- Condensator cleaning warning sign
- Filter cleaning warning sign
- Buzzer sign
- Child lock warning sign
- Water tank warning sign
- Time delay sign
- Start/Stand-by sign
- Program progress bar
- Steam tank warning sign

\*Duration on screen specifies the time remaining for program finish and varies based on the dampness of the clothes.

# Operating the product

## 5.3 Preparing the Machine

1. Plug the machine"
2. Place laundry into the machine.
3. Press On/Off/Cancel button for 1 second (long).
4. When your machine is turned on for the first time, it turns on with the declaration program (cotton wardrobe dry).



Pressing the **On/Off/Cancel** button does not mean that the program started. Press the **Start / Stand-by** button to start the program.

## 5.4 Program selection

1. Determine the suitable program from the table below where drying levels are presented.
2. Use the **Program Selection** button to select the program you wish.

Extra Dry	Only cotton clothes are dried under normal temperature. Thick and multi-layered laundry (towels, bed sheets, denim trousers etc.) are dried so that they can be placed in wardrobe without ironing.
Wardrobe Dry	Normal laundry (tablecloths, underwear etc.) are dried so that they can be placed in wardrobe without ironing.
Iron Dry	Normal laundry (shirts, dresses etc.) are dried to be ready for ironing.



For detailed program information, see "Program selection and consumption chart".

## 5.5 Main programs

The following main programs are available depending on fabric type.

### • Cotton

Dry durable laundry with this program. It dried under normal temperature. It is recommended for your cotton laundry (bedsheets, bedding, towel, bathrobe etc.)

### • Synthetic

Dry sensitive laundry with this program. It is recommended for your synthetic laundry.

## 5.6 Additional programs

The following additional programs are available in the machine for special situations.



Additional programs may vary depending on the features of your machine.

### • Quilt

Dry fibre quilts with a label that indicates it can be dried in drying machine. Ensure that you have loaded the quilt correctly to prevent damage to the machine and the quilt. Remove the quilt cover before loading the quilt to the machine. Load the quilt to the machine after folding it in two.

- Do not load more than 1 double size fibre quilt (200x200 cm). Do not dry items that contain cotton material such as quilts, pillows etc.
- Do not dry items other than quilts such as carpets, rugs, hall rugs etc. This may cause permanent damage to your machine.

### • Shirt 30

Use this program to prepare 2 shirts ready for ironing in 30 minutes.

### • Denim

Use to dry denim clothes wrung in the washing machine with high speed.

### • Fashion

Allows safely drying of your t-shirts, blouses and shirts that include "can be dried" in their washing instructions.

### • Mixed

Use to dry synthetic and cotton clothes that don't give out colour together.

## Operating the product

### • Delicate

You can dry your delicate clothes suitable for drying or clothes that are recommended for hand wash (silk blouses, thin underwear etc.) under low temperatures.



It is recommended to dry your delicates in a laundry bag to prevent wrinkles and damage. When the program ends, take out your laundry immediately and hang them to prevent wrinkles.

### • Refreshing

Ventilates for 10 minutes without blowing hot air. You can ventilate the cotton and linen clothes that have been enclosed for a long time with this program to remove their odour.

### • Basket / Timer.






You can select the timer programs from 10 mins to 160 mins to achieve the desired final drying level under low temperature. In this program, the dryer dries for the time set, regardless of the dryness of the laundry. This product is suitable for the usage of a drying basket as an option. You may perform drying by using the timing programs explained above with the drying basket that you may procure from the authorized service. Refer to Section 5.18 Drying Basket for the details of using a drying basket.




In this program, the machine dries for the duration set, regardless of the drying level.

# Operating the product


## 5.7 Program selection and consumption chart

EN					
Programs	Capacity (kg)	Spin speed in washing machine (rpm)	Approximate amount of remaining humidity	Drying Time (Minutes)	
<b>Cottons / Coloreds</b>					
 Extra dry	9	1000	% 60	230	
 Cupboard dry	9	1000	% 60	209	
 Iron dry	9	1000	% 60	160	
Jeans	4	1200	%50	130	
Shirts 30	1.5	1200	%60	30	
Sport	4	1000	%60	115	
Delicates	2	600	%50	55	
Mix	4	1000	% 60	110	
Bedding	2.5	1000	% 60	164	
<b>Synthetics</b>					
 Cupboard dry	4.5	800	% 40	80	
 Iron dry	4.5	800	% 40	60	
<b>Energy consumption values</b>					
Programs	Capacity (kg)	Spin speed in washing machine (rpm)	Approximate amount of remaining humidity	Energy consumption value kWh	
Cottons linen Ready to wear*	9	1000	% 60	2.14	
Cottons Ready to iron	9	1000	% 60	1.65	
Synthetics Ready to wear	4.5	800	% 40	0.75	
Power consumption of the off-mode for the standard cotton programme at full load, PO (W)				0,5	
Power consumption of the left-on mode for the standard cotton programme at full load, PL (W)				1,0	
Contains fluorinated greenhouse gases covered by the Kyoto Protocol. Hermetically sealed. R134a / 0,30 kg - GWP:1430 - 0,429 tCO <sub>2e</sub>					

 „Cotton cupboard dry programme“ used at full and partial load is the standard drying programme to which the information in the label and the fiche relates, that this programme is suitable for drying normal wet cotton laundry and that it is the most efficient programme in terms of energy consumption for cotton.

\* : Energy Label standard program (EN 61121:2012)

All the values on the chart are identified according to EN 61121:2012 standard. Consumption values may vary from the valued in the chart depending on laundry type, wringing speed, ambient conditions and voltage levels.

 Discharge the condensation water via a hose that is condensed in cotton programs.

# Operating the product

## 5.8 General Description of Steam Programs

Programs	Monitoring Duration	Program Definition	Capacity
Official	28 min.	This program can be used for cotton clothes (shirts, jackets, pants etc). This program will ensure that unwanted odours are removed from your clothes. You can put your laundry into the cupboard without ironing. Only for dry clothes.	1.5 kg or 5-6 pieces of shirts
	22 minutes		1 kg or 3-4 pieces of shirts
	16 minutes		0.5 kg or 1-2 pieces of shirts
Daily	31 minutes	You can use this program for your daily cotton or synthetic laundry. This program will ensure that unwanted odours are removed from your clothes. You can put your laundry into the cupboard without ironing. Only for dry clothes.	1.5 kg or 5-6 pieces of t-shirts
	25 minutes		1 kg or 3-4 pieces of t-shirts
	20 minutes		0.5 kg or 1-2 pieces of t-shirts
Easy ironing Synthetics	45 minutes	You can use this program for synthetic clothes that will be ironed. This program will ensure that your dried clothes are ready in the closet for ironing. For wet and dry laundry.	1.5 kg or 5-6 pieces of shirts
	40 minutes		1 kg or 3-4 pieces of shirts
	35 minutes		0.5 kg or 1-2 pieces of shirts
Easy ironing Cotton	50 minutes	You can use this program for cotton clothes that will be ironed. This program will ensure that your dried clothes are ready in the closet for ironing. For wet and dry laundry.	1.5 kg or 5-6 pieces of shirts
	45 minutes		1 kg or 3-4 pieces of shirts
	40 minutes		0.5 kg or 1-2 pieces of shirts

# Operating the product

## 5.9 Steamy programs

The steam programs you will use will allow you to reduce odour in laundry and minimize wrinkles. Laundry should be separated with respect to its type and size.



When steam programs are on, some noise may be generated in addition to vapour generation.

The result given by the process of wrinkle removing and odour removing may be different according to type and amount of laundry and program selected.

Upon completion of steam programs, laundry should be immediately extracted from the machine and hung out for at least 15 minutes.

### Activating the machine

Prior to first use of steam programs, you must fill the steam tank. For the first use, you may use distilled water provided with the machine. Fill the filling vessel provided with the machine with distilled water.




Do not drink pure (distilled) water.


You may use condensed water to fill the steam tank. For this, water should be filtered. You may fill the filling vessel with condensed water accumulated in the water tank.

### Filling steam tank:


1. Turn on the machine, and move the program key onto one of steam programs.




2. The symbol below shall flash when a steam program is selected as the steam tank is empty.



3. Pull the water tank out.
4. Lift the cap of the steam tank as shown.




5. Use the filling vessel filled with distilled water or condensed water to fill the steam tank.



## Operating the product

6. The symbol on the display shall illuminate continuously when required amount of water is added. In this case, at least one circulation steam program can be used. You may fill water until water level rises up to steam tank filling outlet.




7. Close the outlet of the filling outlet of the steam tank and replace the water tank into the socket.

Note: If the steam tank is empty, then the warning icon will flash and the program will not run.

### Operating the machine

The preferred Steam program is selected. After filling the steam tank, amount of steam will be determined based on amount of laundry. To do that, use the button to select amount of steam.



Selecting any Steam program will show the amount of time maximum amount of steam will be applied on the screen. If the button is pressed once, the amount of time for medium level of steam will be shown, and if it is pressed twice, the amount of time for minimum level of steam will be shown. If the button pressed once more, it will redirect you to the amount of time for maximum level of steam.

Place appropriate amount and type of laundry in the machine.

Push Start/Pause button to run the machine:


Note: Do not open the door when steam programs are on. Hot water may be expelled.



The steam programs for preparing for ironing will deliver the laundry wet for ease of ironing. It is not suitable to wear.


## 5.10 Auxiliary functions

### Audible warning

 Machine makes an audible warning when the program is completed. To adjust the sound level, use the **Sound Warning Level** button.



You can change the sound level before the program starts or while the program continues.



### Wrinkle prevention

If the laundry is not removed after the program is completed, the wrinkle prevention program activates for 2 hours to prevent the laundry inside the machine to get wrinkled. The program tumbles the laundry with 10-minute intervals to prevent them from wrinkling.

## 5.11 Warning symbols




Warning symbols may vary depending on the model of your machine.

### Fibre filter cleaning

When the program is completed, the warning symbol for filter cleaning turns on.



Refer to "Troubleshooting" section if filter cleaning symbol constantly flashes.



### Water tank

When the program is completed, the warning symbol to empty the water tank turns on.

If the water tank fills up while the program continues, the warning symbol starts flashing and the machine goes into stand-by. In this case, empty the water tank and start the program by pressing the **Start / Stand-by** button. Warning symbol turns off and program resumes.



# Operating the product

## Cleaning the filter drawer

Warning symbol flashes periodically to remind that filter drawer must be cleaned.



## Time Delay

You can delay the start of the program for up to 24 hours using the Time Delay function.

1. Open the loading door and place the laundry.
2. Select drying program and if needed, additional functions.
3. Press the Time Delay selection button and set the delay time you wish. Time Delay sign is displayed on the screen. (If you keep the button pressed, the time delay switches continuously).
4. Press the **Start / Stand-by** button. Delay Time countdown starts and Delay Time symbol turns on. ":" separator in the middle of displayed delay time flashes.



You can add or remove laundry during the Time Delay duration. Delay Time symbol will turn off at the end of Delay Time countdown, drying starts and duration of program is displayed. Displayed time is the sum of normal drying time and Delay Time.

## Changing the Time Delay duration

If you want to change the duration during the countdown:

1. Press the **On/Off/Cancel** button for 3 seconds to cancel the program. Turn on the machine again and repeat the Time Delay steps for the duration you wish.
2. When your machine is turned on for the first time, it turns on with the declaration program (cotton wardrobe dry).

## Cancelling the Time Delay function

If you want to cancel the Time Delay countdown and start the program immediately:

1. Press the **On/Off/Cancel** button for 3 seconds to cancel the program.
2. Press the **On/Off/Cancel** button to start you previously selected program.

## 5.12 Starting the program

Press the **Start/Stand-by** button to start the program. Indicating start of the program, **Start** ► symbol turns on, ":" separator in the middle of remaining time keeps flashing.

## 5.13 Child Lock

The machine has a child lock which prevents the program flow from being interrupted when the buttons are pressed during a program. When the child lock is activated, all buttons on the panel except the **On/Off/Cancel** button are deactivated.

To activate the child lock, keep the Sound Warning and Child lock buttons pressed for 3 seconds.

The child lock has to be deactivated to be able to start a new program after the current program is finished or to be able to interfere with the program. **To deactivate the child lock**, keep the same buttons pressed for 3 seconds.



When the child lock is activated, the lock symbol on the screen turns on.



Child lock deactivates when the machine is turned off and on by the **On/Off/Cancel** button.

- When the child lock is active:
- The machine runs, or in stand-by state the indicator symbols won't change upon changing the position of the program selection button.

## 5.14 Changing the program after it is started

You can change the program you selected to dry your laundry with a different program after the machine starts running.

1. For example, to select Extra Dry instead of Iron Dry, pause the program by pressing the Start / Stand-by button for 1 second.
2. Select the Extra Dry program using the Program Selection button.
3. Press the Start/Stand-by button to start the program.

## Operating the product

### Adding and removing clothes during stand-by

If you want to add or remove clothes to/from the machine after the drying program starts:

1. Press the Start/Stand-by button to put the machine in Stand by state. The drying operation stops.
2. Open the loading door while in Stand-by state, and close the door after you remove or add laundry.
3. Press the Start/Stand-by button to start the program.



Adding laundry after the drying operation starts may cause the dried laundry inside the machine to mix with wet laundry and leave the laundry damp at the end of operation.



Adding or removing laundry during drying may be repeated as many times as you wish. But this operation continuously interrupts the drying operation, and thus increases program duration and energy consumption. So, it is recommended to add laundry before the program starts.



If a new program is selected by turning the program selection knob while the machine is in stand-by; the running program terminates and new program information is displayed on the screen.



**WARNING:** Do not touch the inner surface of the drum while adding or removing clothes during a continuing program. The drum surface is hot.

### 5.15 Cancelling the program

If you want to cancel the program and terminate the drying operation for any reason after the machine starts running, keep the **On/Off/Cancel** button pressed for 3 seconds.



**WARNING:** The inside of the machine shall be extremely hot when you cancel the program during machine operation, so run the ventilation program to allow it to cool down.

### 5.16 End of program

When the program ends, the Fibre Filter Cleaning and Water Tank warning symbols on the program observation indicator turn on. Loading door may be opened and machine becomes ready for another run.

To turn off the machine, press the **On/Off/Cancel** button.



2 hour-Wrinkle Prevention program is activated if laundry isn't taken out of machine after completion of the program.



Clean the fibre filter after each drying. (See "Fibre filter and Loading door inner surface")



Empty the water tank after each drying. (See "Emptying the water tank")


### 5.17 Odour feature

Your drying machine is equipped with odour feature. Read the ProScent operation manual for the usage of this feature.

There are 3 different scent options that you may use on your machine. Fresh, Flower / Rose, Ocean.


Your machine contains one type of scent capsule, you may obtain the other scent capsules from the authorized services. Use the scent capsules procured from the authorized services only.

## 5.18 Drying Basket



# Operating the product

## General Appearance of the Basket



# Operating the product

## Placing the Basket in the Basket:

Wool Program in the Basket:

Wool Program in Basket allows you to dry your pants, skirts, wool sweaters and sneakers without spinning in the drum thanks to a racked basket that is placed in the drum.



In your device, Wool Program in the Basket and Timer programs are paired. Based on your needs, you can use with or without a basket. The descriptions and warnings are based on the assumption that you are using a basket.



Do not initiate the wool program in the basket without placing the basket in the drum.



Use the racked basket only for wool program in the basket program; do not use for other programs.



Before placing the sneakers inside the basket, place the racked basket in the machine and open the racks.

In the laundry placement in the basket section, sweaters, pants, skirts, sneakers and gloves placement are described. Before placing the sneakers in the basket, move the sneaker flaps out and take the shoelaces away. Place the gloves through their wrist sections on the racks as shown in the figure. Select the wool program in the basket via the program button. By using the program duration button on the control panel, the desired duration can be adjusted up to 160 minutes.

## Placing the Basket in the Machine:



After placing the laundry in the basket, place the basket in the machine.




Before placing the basket in the machine and remove it from the machine, detach the racks on the basket.

## Recommended Loads and Drying Durations:


The provided rates are guidance rates.

If required, initiate additional drying.


Load Type	Programme duration (min.)
Wool Sweater	120 - 140
Pants	140 - 160
Accessories such as gloves	60 - 80
Skirts	100 - 120
Sneakers (max. 1 kg)	120 - 140




3 – General view of the basket in the machine.



1 - Insert the basket in the machine with the lower section of the basket going in the machine first.



2 - Attach the basket to the machine via the two sockets.



## 6 Maintenance and cleaning

Service life of product extends and frequently experienced problems will be reduced if it is cleaned at regular intervals.

### 6.1 Cleaning Lint Filter / Loading Door Inner Surface

Lint and fiber released from the laundry to the air during the drying cycle are collected in the Lint Filter.



Such fiber and lint are generally formed during wearing and washing.




Always clean the lint filter and the inner surfaces of the loading door after each drying process.



You can clean the lint filter housing with a vacuum cleaner.







- A layer can build up on the filter pores that can cause clogging of the filter after using the dryer for a while. Wash the lint filter with warm water to remove the layer that builds up on the lint filter surface. Dry the lint filter completely before reinstalling it.



- Clean the entire inner surface of the loading door and loading door gasket with a soft damp cloth.

To clean the lint filter:

- Open the loading door.
- Remove the lint filter by pulling it up and open the lint filter.
- Clean lint, fiber, and cotton raveling by hand or with a soft piece of cloth.
- Close the lint filter and place it back into its housing.



# Maintenance and cleaning

## 6.2 Cleaning the sensor

There are dampness sensors in the dryer that detect whether the laundry is dry or not.

To clean the sensors:

- Open the loading door of the dryer.
- Allow the machine to cool down if it is still hot due to the drying process.
- Wipe the metal surfaces of the sensor with a soft cloth, dampened with vinegar and dry them.




Clean metal surfaces of the sensors 4 times a year.



Do not use metal tools when cleaning metal surfaces of the sensors.



Never use solvents, cleaning agents or similar substances for cleaning due to the risk of fire and explosion!



## 6.3 Draining the water tank

Dampness of the laundry is removed and condensed during drying process and the water that arise accumulates in the water tank. Drain the water tank after each drying cycle.



Condensed water is not drinkable!




Never remove the water tank when the program is running!


If you forget to drain the water tank, the machine will stop during the subsequent drying cycles when the water tank is full and the Water Tank warning symbol will flash. If this is the case, drain the water tank and press **Start / Pause** button to resume the drying cycle.

To drain the water tank:

- Pull the drawer and remove the water tank carefully.



- Drain the water in the tank.



- If there is lint accumulation in the funnel of the water tank, clean it under running water.
- Place the water tank into its seat.



If the direct water draining is used as an option, there is no need to empty the water tank.

## Maintenance and cleaning


### 6.4 Cleaning the filter drawer

Lint and fiber that could not be captured by the lint filter are blocked in the filter drawer behind the kick plate. Filter Drawer Cleaning warning light will light up maximum at every 5 drying cycles as a reminder.


There is a two-level filter in the filter drawer. The first level is the filter drawer sponge and the second level is the filter cloth.

To clean the filter drawer:


- Press the kick plate button to open the kick plate.




- Remove the filter drawer cover by turning it in the direction of arrow.




- Pull out the filter drawer.




- Open the filter drawer by pressing the red button.



- Take out the filter drawer sponge.



- Clean lint, fiber, and cotton raveling on the filter cloth by hand or with a soft piece of cloth.
- When you notice a layer that may lead clogging on the filter cloth, please clean the layer by washing in warm water. Let the filter cloth dry thoroughly before installing back the filter drawer.




- Wash the filter drawer sponge by hand to remove the fiber and lint on the surface. After washing the sponge, squeeze it by hand and remove the excess water. Well-dry the sponge before storing it.




It is not necessary to clean the sponge if lint and fiber accumulation on it is not significant.

- Place the sponge back into its place.




- Close the filter drawer as to lock the red button.




## Maintenance and cleaning

- Place the filter drawer back into its place, turn the filter drawer cover in the arrow direction and close it securely.



- Close the kick plate cover.





Drying without the filter drawer sponge in place will damage the machine!



A dirty lint filter and filter drawer will cause longer drying periods and higher energy consumption.

### 6.5 Cleaning the evaporator


Clean the lint accumulated on the fins of the evaporator located behind the filter drawer with a vacuum cleaner.




You can also clean by hand provided that you wear protective gloves. Do not attempt to clean with bare hands. Evaporator fins can harm your hand.

### 6.6 Steam cleaning of equipment

Clean the filling port when it is dirty or blocked. Remove the water tank by pulling it out, remove the steam tank filling port cover. Open the cover and turn it upside down and wash it under tap water.



Remove the filling tank cover by rotating it on the direction of arrow when it is dirty or blocked and wash it under tap water.



## 8 Troubleshooting

### Drying process takes too much time.

- Pores of the lint filter are clogged. >>> Wash the lint filter with warm water.
- Filter drawer is clogged. >>> Clean the sponge and the filter cloth in the filter drawer.
- Ventilation grids on the front side of the machine are blocked. >>> Remove the objects (if any) that block ventilation in front of the ventilation grids.
- Ventilation may not be sufficient since the room where the machine is installed is very small. >>> Open the door and windows of the room to avoid the room temperature increase too much.
- Lime deposit has built up on the dampness sensor. >>> Clean the dampness sensor.
- Excessive laundry might have been loaded in. >>> Do not overload the dryer.
- Laundry might not be spun sufficiently. >>> Spin your laundry at a higher speed in your washing machine.

### Laundry comes out wet at the end of drying.

- A programme suitable for the laundry type might have not been used.>>> Check the garment tag and select a programme suitable for the fabric type or use the timer programmes additionally.
- Pores of the lint filter are clogged. >>> Wash the lint filter with warm water.
- Filter drawer is clogged. >>> Clean the sponge and the filter cloth in the filter drawer.
- Excessive laundry might have been loaded in. >>> Do not load the dryer in excess.
- Laundry might not be spun sufficiently. >>> Spin your laundry at a higher speed in your washing machine.

### Dryer does not switch on or the programme does not start. Dryer does not start when it is set.

- It might have not been plugged in. >>> Make sure that the machine is plugged in.
- The loading door is ajar. >>> Make sure that the loading door is closed securely.
- Programme is not selected or the Start / Pause button is not pressed. >>> Make sure that the programme is selected and it is not in the Pause position.
- "Child Lock" might have been activated. >>> Deactivate the Childproof Lock.

### Programme is interrupted without any cause.

- The loading door might not be closed securely. >>> Push the loading door to close until you hear a locking sound.
- A power failure might have occurred. >>> Press Start / Pause button to start the programme.
- Water tank may be full. >>> Drain the water tank.

### Laundry has shrunk, become felted or deteriorated.

- A programme suitable for the laundry type might have not been used. >>> Check the garment tag and select a programme suitable for the fabric type.

### Water leaks from the loading door.

- Lint has accumulated on the inner surfaces of the loading door and on the surfaces of the loading door gasket. >>> Clean the inner surfaces of the loading door and the surfaces of the loading door gasket.

### Loading door opens spontaneously.

- The loading door might not be closed securely. >>> Push the loading door to close until you hear a locking sound.

### Water Tank warning symbol is on/flashing.

- Water tank may be full. >>> Drain the water tank.
- Water draining hose might be bent. >>> If the product is connected directly to a wastewater drain, check the water drain hose.

### Steam icon flashes.

- *Steam tank may be empty => Fill the steam tank with distilled or condensed water.*

### Steam program does not start

- *Steam tank may be empty, steam tank warning icon may light on the screen => Fill the steam tank until the steam icon goes off.*

### **Wrinkles are not removed within wrinkle removing program.**

- *Excess amount of laundry may have been placed => Place specified amount of laundry.*
- *Steam application time may be selected in low level => Choose a program with high amount of steam.*
- *After completion of the program, the laundry may have stayed in the machine for a long time => Take the laundry out as soon as the program finishes, and hang out it.*

### **Odour removing program does not reduce odour of laundry**

- *Excess amount of laundry may have been placed => Place specified amount of laundry.*
- *Steam application time may be selected in low level => Choose a program with high amount of steam.*



**CAUTION:** If you cannot eliminate the problem although you follow the instructions in this section, consult your dealer or the Authorised Service Agent. Never try to repair a nonfunctional product yourself.

**DECLARATION OF CONFORMITY**

Name of the Manufacturer : Arçelik A.Ş. Çamaşır Kurutma Makinesi İşletmesi  
Address of the Manufacturer : Örg.San. Böl. Atatürk Cad. B. Sk. No:6 59500 Çerkezköy/Tekirdağ/Turkey  
Contact information of the Manufacturer : +90 282 736 5360  
Authorized Person of the Manufacturer : Bang Tekdemir

Concerning the European directives and regulations for electrical and electronic equipment listed in this document,

We, Arçelik A.Ş.,

hereby declare and take the sole responsibility that the product below, to which this declaration is involved,

Type of Product : Tumble Dryer  
Brand Name : ARÇELIK  
Product Identity Code : 3836 CNT  
Product Model Code : H958H22

fulfills the requirements of the following directives and the related regulations;

- the low-voltage directive 2006/95/EC
- the EMC directive 2004/108/EC
- the R&TTE directive 1999/5/EC
- the RoHS directive 2002/95/EC
- the stand-by regulation 1275/2008
- the RoHS directive 2011/65/EU

and is in conformity with the relevant harmonized standards listed below:

- EN 60335-1:2012+AC:2014+A11:2014
- EN 60335-1/A15 (VDE 0700-1/A15):2012-03; EN 60335-1/A15:2011
- EN 60335-2-11:2010+A11:2012
- EN 60335-2-11 (VDE 0700-11):2011-04
- EN 62233 (VDE 0700-366):2008-11
- EN 62233:2008
- EN 62233 Ser.1 (VDE 0700 - 366 Ser.1):2009-04
- EN 62233 Ser.1:2008
- EN 55014-1:2006+A1:2009+A2:2011
- EN 55014-2:1997+A1:2001+A2:2008 / AC:1997
- EN 61800-3-2:2006+A1:2009+A2:2009
- EN 61800-3-3:2013
- EN 50564:2011
- EN 61121:2013
- EN 50561:2012
- EN 301489 1 V1.9.2:2011 / EN 301489 1 V2.2.1:2012

Tekirdağ, TURKEY B 21.04.2016

Place and Date

Bang Tekdemir

R&D Manager



The Year CE declaration is implemented on the product is 2014

name, surname, position and signature or  
the equal data of the authorized person